



Fantastik®

Multi-Surface Disinfectant Degreaser ONE PRODUCT

TO STREAMLINE YOUR CLEANING PROCESS!
CLEANS - DISINFECTS - DEGREASES - DEODORIZES



MULTI-PURPOSE DAILY CLEANER FOR
INDOOR AND OUTDOOR USE

- Proven to kill the COVID-19 virus (SARS-CoV-2) on hard, non-porous surfaces.
- Kills 99.99% of viruses^ and bacteria* when used as directed on hard, non-porous surfaces.
- Removes 100% tough soap scum and grease
- Leaves a pleasant scent

*SARS-CoV-2, Human Coronavirus, Influenza A (H1N1) virus, Rotavirus, Herpes simplex virus type 1 and 2.
^Staphylococcus aureus (staph), Streptococcus pyogenes (strep), Salmonella enterica, Listeria monocytogenes, Escherichia coli O157:H7 (E. coli), Pseudomonas aeruginosa, Enterococcus faecalis, Methicillin Resistant Staphylococcus aureus (MRSA).
Use pesticides safely. Always read label and product information before use.

***Trigger Bottle (311837) Made of 100% Post-consumer Recycled Plastic. Gallon Bottle (311929), Minus Cap, Made of 48% Post-consumer Recycled Plastic.

USE OVERVIEW

FOR USE IN:

- Businesses
- Offices
- Restaurants
(rinse surfaces with potable water)
- Retail Stores
- Hotels & Motels
- Bed and Breakfast Inns
- Convenience Stores
- Automotive Shops
- Buses
- Cars
- Cruise Ships
- Airplanes

Cleans, disinfects and deodorizes kitchen and bath hard non-porous surfaces.

Cleans appliances, refrigerator exteriors, dishwasher exteriors, countertops*, cooktops*, stovetops*, oven exteriors, bathroom fixtures, sinks, showers, toilets, floors and siding.

Use on stainless steel, chrome fixtures, aluminum, bronze, brushed nickel, (synthetic) sealed granite, sealed marble, quartz, acrylic, fiberglass and tile.

Kitchen countertops and similar, food contact surfaces must be rinsed with clean potable water following application.

*Allow surface to adjust to room temperature

TO CLEAN:

Spray (15-20cm) from surface until thoroughly covered. For tough jobs, let stand several minutes before wiping.

TO DISINFECT:

Spray 15 - 20 cm from surface until thoroughly wet. Allow surface to remain wet for 5 minutes and wipe. Pre-clean heavily soiled areas. Avoid contact with food. For surfaces and/or objects that may come into direct contact with food, a rinse with potable water is recommended. For surfaces and/or objects that may come into direct contact with children at the mouthing stage of development, a rinse with potable water is recommended.

PRECAUTIONARY STATEMENTS:

KEEP OUT OF REACH OF CHILDREN AND PETS.

Do not apply this product around electrical equipment due to the possibility of shock hazard. Take the container label or product name and Drug Identification Number (DIN) with you when seeking medical attention.

STORAGE AND DISPOSAL

STORAGE:

Store in a cool, dry place, in original container out of reach of children and pets.

DISPOSAL:

Never place unused product down any indoor or outdoor drain. For information on disposal of unused, unwanted product, contact the manufacturer or the appropriate municipal/provincial/territorial agency or product stewardship organization.

CONTAINER HANDLING:

Refillable Container. Refill this container with fantastik® Multi-Surface Disinfectant Degreaser only. Do not reuse this container for any other purpose. (3.78L Refill Bottle). Non-refillable container. Do not reuse or refill this container. Securely wrap original in several layers of newspaper and discard in trash or offer for recycling if available.

ORDERING INFORMATION

Description

fantastik® Multi-Surface Disinfectant Degreaser Trigger, 946mL, Case Qty 8
fantastik® Multi-Surface Disinfectant Degreaser Refill, 3.78L, Case Qty 4

Case UPC

100-6291300078-9
100-6291300079-6

SCJ Code

311837
311929

SC Johnson Professional CA Inc.
Brantford, ON N3T 5R1
1-888-332-7627
www.scjp.com